








E.Z.N.A.[®] Forensic DNA Kit




D3591-00	5 preps
D3591-02	200 preps

Manual Date: August 2025
Revision Number: v7.0

For Research Use Only

 Omega Bio-tek, Inc.
400 Pinnacle Way, Suite 450
Norcross, GA 30071
 www.omegabiotek.com

 770-931-8400
 770-931-0230
 info@omegabiotek.com

 [omega-bio-tek](https://www.linkedin.com/company/omega-bio-tek)
 [omegabiotek](https://twitter.com/omegabiotek)
 [omegabiotek](https://www.facebook.com/omegabiotek)

E.Z.N.A.® Forensic DNA Kit

Table of Contents

Introduction and Overview.....	2
Kit Contents/Storage and Stability.....	3
Preparing Reagents.....	4
Guidelines for the Vacuum Manifold.....	5
Standard Protocol.....	6
Fresh or Frozen Sperm.....	10
Buccal Swabs.....	14
Bacteria from Biological Samples.....	18
Saliva.....	21
Hair, Nails, and Feathers.....	24
Vacuum/Spin Protocol.....	27
Troubleshooting Guide.....	31

Manual Date: August 2025

Revision Number: v7.0



Introduction and Overview

The E.Z.N.A.® Forensic DNA Kit is designed to provide a rapid and easy method for the isolation of genomic DNA from forensic samples such as dry blood, buccal swabs, and semen samples for consistent PCR and Southern analysis. This kit can also be used for the preparation of genomic DNA from mouse tail snips, whole blood, buffy coat, serum, and plasma. This kit can process single or multiple samples simultaneously. There is no need for phenol/chloroform extractions and time-consuming steps such as precipitation with isopropanol or ethanol are eliminated. DNA purified using the E.Z.N.A.® Forensic DNA Kit is ready for applications such as PCR*, Southern blotting, and restriction enzyme digestion.

E.Z.N.A.® Forensic DNA Kits combine the reversible DNA binding properties of the HiBind® matrix, a new silica-based material, with the speed of mini-column centrifugation to quickly purify high-quality DNA. A specifically formulated buffer system allows genomic DNA up to 50 kb to bind to the matrix. Samples are lysed under denaturing conditions and then applied to the HiBind® DNA Mini Columns. The HiBind® matrix selectively binds DNA; therefore, cellular debris, hemoglobin, and other proteins can be easily eliminated during the washing procedures. High-quality DNA is eluted in sterile deionized water or elution buffer. Each HiBind® DNA Mini Column can bind approximately 100 µg DNA from up to 30 mg tissue or 1×10^7 cells; although, using more starting material is not recommended.

Determination of Yield and Quality

The total DNA yield can be determined by a spectrophotometer using deionized water, Tris-HCl buffer, or Elution Buffer as blank. DNA concentration is calculated as:

$$[\text{DNA}] = (\text{Absorbance}_{260}) \times (0.05 \text{ } \mu\text{g}/\text{ } \mu\text{L}) \times (\text{Dilution factor})$$

The quality of DNA can be assessed by measuring absorbance at both 260 nm and at 280 nm. A ratio of (A_{260}/A_{280}) of 1.7-1.9 corresponds to 85%-95% purity. Yields vary with both amount and type of tissue used. Generally, 30 mg of fresh tissue will yield 10-40 µg DNA with two elutions of 200 µL each.

New in this Edition:

August 2025

- Updated protocol sections to specify when additional reagent volumes are required beyond kit contents.

January 2024

- The 50 prep pack size (D3591-01) has been discontinued and is no longer available to purchase.

March 2019

- OB Protease Solution has been renamed Proteinase K Solution. This is a name change only. The formulation has not changed.

Kit Contents

Product	D3591-00	D3591-02
Purifications	5 preps	200 preps
HiBind® DNA Mini Columns	5	200
2 mL Collection Tubes	15	600
BL Buffer	1.5 mL	50 mL
TL Buffer	1.1 mL	44 mL
HBC Buffer	5 mL	80 mL
DNA Wash Buffer	2.5 mL	3 x 25 mL
Elution Buffer	15 mL	60 mL
Proteinase K Solution	150 µL	5.5 mL
User Manual	✓	✓

Note: The E.Z.N.A.® Forensic DNA Kit is supplied with enough buffer for the Standard Protocol (Page 6) for dried blood, body fluids, and saliva samples. Supplemental protocols that are included for specialized sample types (such as the buccal swabs, hair, nails, and semen), may require higher buffer volumes. For these protocols, the total number of purifications that can be performed will need to be reduced. If you are using one of these protocols, additional buffers can be purchased separately from Omega Bio-tek, Inc.

Storage and Stability

All E.Z.N.A.® Forensic DNA Kit components are guaranteed for at least 12 months from the date of purchase when stored as follows: Proteinase K Solution can be stored at room temperature for 12 months. For long-term storage (>12 months), store at 2-8°C. Store all other components at room temperature (15-25°C) and away from bright light. During shipment or storage in cool ambient conditions, precipitates may form in some buffers. Dissolve such deposits by warming the solution at 37°C and gently shaking.

Preparing Reagents

1. Dilute DNA Wash Buffer with 100% ethanol as follows and store at room temperature.

Kit	100% Ethanol to be Added
D3591-00	10 mL
D3591-02	100 mL per bottle

2. Dilute HBC Buffer with 100% isopropanol as follows and store at room temperature.

Kit	100% Isopropanol to be Added
D3591-00	2 mL
D3591-02	32 mL


Guidelines for Vacuum Manifold

The following is required for use with the Vacuum Protocol:

- A) Vacuum Manifold
- B) Vacuum Flask
- C) Vacuum Tubing
- D) Vacuum Source (review tables below for pressure settings)

Conversion from millibars:	Multiply by:
millimeters of mercury (mmHg)	0.75
kilopascals (kPa)	0.1
inches of mercury (inHg)	0.0295
Torr (Torr)	0.75
atmospheres (atm)	0.000987
pounds per square inch (psi)	0.0145

Illustrated Vacuum Setup:



E.Z.N.A.[®] Forensic DNA Kit Protocols

Standard Protocol

Dried blood, body fluids, and semen samples on filter paper can be processed using the following method.

Materials and Reagents to be Supplied by User:

- 1.5 mL or 2.0 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- Microcentrifuge capable of 14,000g
- Vortexer
- Water baths or heat blocks capable of 55°C, 60°C and 70°C
- 100% ethanol
- 100% isopropanol
- Optional: 3M NaOH

Before Starting:

- Heat the water baths or heat blocks to 55°C and 60°C
- Heat the Elution Buffer to 70°C
- Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4

1. Cut or punch out the blood spot (or other sample) from the filter paper. (Up to 200 μ L of blood can be used for each spot.) Tear or cut filter into small pieces and place into a microcentrifuge tube (not provided).

Note: Use 3-4 punched circles (3 mm diameter) for each DNA isolation.

2. Add 200 μ L TL Buffer. Vortex to mix thoroughly.
3. Incubate at 55°C for 15 minutes. Vortex every 2 minutes to mix.
4. Add 25 μ L Proteinase K Solution. Vortex to mix thoroughly.
5. Incubate at 60°C for 45 minutes with occasional mixing.

E.Z.N.A.[®] Forensic DNA Kit Protocols

6. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
7. Add 225 μL BL Buffer. Vortex to mix thoroughly.
8. Incubate at 60°C for 10 minutes.
9. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
10. Add 300 μL 100% isopropanol. Vortex to mix thoroughly.
11. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
12. Insert a HiBind[®] DNA Mini Column into a 2 mL Collection Tube.

Optional Protocol for Column Equilibration:

1. Add 100 μL 3M NaOH to the HiBind[®] DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Centrifuge at maximum speed for 30 seconds.
 4. Discard the filtrate and reuse the collection tube.
13. Transfer the entire sample from **Step 11** to the column, including any precipitate that may have formed.
 14. Centrifuge at maximum speed for 1 minute.
 15. Discard the filtrate and the collection tube.
 16. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.

E.Z.N.A.[®] Forensic DNA Kit Protocols

17. Add 500 μ L HBC Buffer.

Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.

18. Centrifuge at maximum speed for 1 minute.

19. Discard the filtrate and the collection tube.

20. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.

21. Add 700 μ L DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

22. Centrifuge at maximum speed for 1 minute.

23. Discard the filtrate and reuse the collection tube.

24. Repeat Steps 21-23 for a second DNA Wash step.

25. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

26. Place the column into a 1.5 mL or 2.0 mL nuclease-free microcentrifuge tube.

27. Add 100 μ L Elution Buffer heated to 70°C.

28. Let sit at room temperature for 3 minutes.

29. Centrifuge at maximum speed for 1 minute.

E.Z.N.A.[®] Forensic DNA Kit Protocols

30. Repeat Steps 27-29 for a second elution step.

Note: Incubation at 70°C will give a modest increase in DNA yield per elution. Using the first eluate for the second elution will increase DNA concentration.

31. Store DNA at -20°C.

Tip: Blood spots from finger pricks usually contain no more than 50 µL blood and yield approximately 500 ng to 1 µg DNA. This is sufficient for PCR analysis. To obtain higher DNA concentrations, elute with 50 µL heated Elution Buffer or TE and repeat the elution step with the first eluate.

E.Z.N.A.[®] Forensic DNA Kit Protocols

Fresh or Frozen Semen

This protocol can be used for fresh or frozen semen samples with equal efficiency. Frozen samples must be completely thawed before use. Note that lysis time will vary depending on the size and density of the source material.

IMPORTANT: Additional Reagents May Be Required

This protocol requires more reagent volumes exceeding those provided in the standard kit protocol, depending on the number of samples processed. The following reagents will need to be purchased separately:

- [BL Buffer](#)

Materials and Reagents to be Supplied by User:

- 15 mL Corex glass centrifuge tubes
- Centrifuge capable of 2,500g
- Vortexer
- 2.0 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- Water bath or heat block capable of 60°C and 70°C
- NaCl, EDTA, Tris-HCl, SDS, β-mercaptoethanol to prepare Buffer A and Buffer B (see table below in the Before Starting section)
- 100% ethanol
- 100% isopropanol
- Optional: 3M NaOH

Before Starting:

- Heat the water bath or heat block to 60°C
- Heat Elution Buffer to 70°C
- Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4
- Prepare the following buffers before beginning:

Buffer A:	150 mM NaCl 10 mM EDTA, pH 8.0	Buffer B:	100 mM Tris-HCl, pH 8.0 10 mM EDTA 500 mM NaCl 1% SDS 2% β-mercaptoethanol
-----------	-----------------------------------	-----------	--

E.Z.N.A.[®] Forensic DNA Kit Protocols

1. Add 50-250 μL semen to 10 mL Buffer A in a 15 mL Corex centrifuge tube.
Note: Using Corex tubes prevents attachment of the sperm cells to the tube walls.
2. Vortex for 10 seconds.
3. Centrifuge at 2,500g for 10 minutes.
4. Carefully aspirate the supernatant leaving \sim 1 mL pellet and Buffer A.
5. Vortex for 10 seconds.
6. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
7. Transfer sample to a new 2.0 mL microcentrifuge tube.
8. Add 500 μL Buffer A to the Corex tube from **Step 4** to rinse the tube.
9. Vortex for 30 seconds.
10. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
11. Transfer sample from **Step 8** to the 2 mL nuclease-free microcentrifuge tube.
12. Centrifuge at maximum speed for 2 minutes.
13. Carefully remove the supernatant without disturbing the semen pellet.
14. Add 200 μL Buffer B and resuspend pellet.

E.Z.N.A.[®] Forensic DNA Kit Protocols

15. Add 250 μ L BL Buffer.
16. Add 260 μ L 100% ethanol. Vortex to mix thoroughly.
17. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
18. Insert a HiBind[®] DNA Mini Column into a 2 mL Collection Tube.

Optional Protocol for Column Equilibration:

1. Add 100 μ L 3M NaOH to the HiBind[®] DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Centrifuge at maximum speed for 30 seconds.
 4. Discard the filtrate and reuse the collection tube.
-
19. Transfer the entire sample from **Step 19** to the column, including any precipitate that may have formed.
 20. Centrifuge at maximum speed for 1 minute.
 21. Discard the filtrate and the collection tube.
 22. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.
 23. Add 500 μ L HBC Buffer.

Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.
 24. Centrifuge at maximum speed for 1 minute.
 25. Discard the filtrate and the collection tube.

E.Z.N.A.[®] Forensic DNA Kit Protocols

26. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.

27. Add 700 μ L DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

28. Centrifuge at maximum speed for 1 minute.

29. Discard the filtrate and reuse the collection tube.

30. Repeat Steps 27-29 for a second DNA Wash step.

31. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

32. Place the column into a 1.5 mL or 2.0 mL nuclease-free microcentrifuge tube.

33. Add 100 μ L Elution Buffer heated to 70°C.

34. Let sit at room temperature for 3 minutes.

35. Centrifuge at maximum speed for 1 minute.

36. Repeat Steps 35-37 for a second elution step.

Note: Incubation at 70°C will give a modest increase in DNA yield per elution. Using the first eluate for the second elution will increase DNA concentration.

37. Store DNA at -20°C.

E.Z.N.A.® Forensic DNA Kit Protocols

Buccal Swabs

This protocol has been tested for the following swab types: cotton and C.E.P. (Life Science). Typical yields from these swabs are 0.5-3 µg DNA.

IMPORTANT: Additional Reagents May Be Required

This protocol requires more reagent volumes exceeding those provided in the standard kit protocol, depending on the number of samples processed. The following reagents will need to be purchased separately:

- [BL Buffer](#)

Materials and Reagents to be Supplied by User:

- 2 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- Microcentrifuge capable of 14,000g
- Vortexer
- Water baths or heat blocks capable of 60°C and 70°C
- PBS
- 100% ethanol
- 100% isopropanol
- Optional: 3M NaOH

Before Starting:

- Heat the Elution Buffer to 70°C
- Heat the water bath or heat block to 60°C
- Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4

1. Scrape the swabs firmly against the inside of each cheek 6 -7 times.

Note: The person providing the sample should not eat or drink for at least 30 minutes prior to the sample collection.

2. Air or vacuum dry the swabs for 2 hours following collection.
3. Separate the swab from the stick and transfer to a 2 mL nuclease-free microcentrifuge tube (not provided).

E.Z.N.A.[®] Forensic DNA Kit Protocols

4. Add 550 μ L PBS.
5. Add 25 μ L Proteinase K Solution.
6. Add 550 μ L BL Buffer. Vortex immediately for 30 seconds.
7. Incubate at 60°C for 30 minutes with occasional mixing.
8. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
9. Add 550 μ L 100% ethanol. Vortex to mix thoroughly.
10. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
11. Insert a HiBind[®] DNA Mini Column into a 2 mL Collection Tube.

Optional Protocol for Column Equilibration:

1. Add 100 μ L 3M NaOH to the HiBind[®] DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Centrifuge at maximum speed for 30 seconds.
 4. Discard the filtrate and reuse the collection tube.
-
12. Carefully add 700 μ L of the sample from **Step 10** to the HiBind[®] DNA Mini Column.
 13. Centrifuge at maximum speed for 1 minute.
 14. Discard the filtrate and reuse collection tube.
 15. Repeat Steps 12-14 until all of the remaining sample has been transferred to the HiBind[®] DNA Mini Column.

E.Z.N.A.® Forensic DNA Kit Protocols

16. Discard the collection tube.

17. Transfer the HiBind® DNA Mini Column to a new 2 mL Collection Tube.

18. Add 500 µL HBC Buffer.

Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.

19. Centrifuge at maximum speed for 1 minute.

20. Discard the filtrate and the collection tube.

21. Transfer the HiBind® DNA Mini Column to a new 2 mL Collection Tube.

22. Add 700 µL DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

23. Centrifuge at maximum speed for 1 minute.

24. Discard the filtrate and reuse the collection tube.

25. Repeat Steps 22-24 for a second DNA Wash step.

26. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

27. Transfer the HiBind® DNA Mini Column to a 2 mL nuclease-free microcentrifuge tube.

E.Z.N.A.[®] Forensic DNA Kit Protocols

28. Add 200 μ L Elution Buffer heated to 70°C.
29. Let sit at room temperature for 3 minutes.
30. Centrifuge at maximum speed for 1 minute.
31. Repeat Steps 31-33 for a second elution step.

Note: Incubation at 70°C will give a modest increase in DNA yield per elution. Using the first eluate for the second elution will increase DNA concentration.

32. Store DNA at -20°C.

Bacteria from Biological Fluids

Materials and Reagents to be Supplied by User:

- 1.5 mL or 2.0 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- Microcentrifuge capable of 14,000g
- Vortexer
- Water baths or heat blocks capable of 55°C, 60°C and 70°C
- 100% ethanol
- 100% isopropanol
- Optional: 3M NaOH

Before Starting:

- Heat the water baths or heat blocks to 55°C and 60°C
- Heat the Elution Buffer to 70°C
- Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4

1. Centrifuge at 5,000g for 10 minutes to pellet bacteria.
2. Add 200 µL TL Buffer and resuspend bacterial pellet.
3. Incubate at 55°C for 15 minutes. Vortex every 2 minutes to mix.
4. Add 25 µL Proteinase K Solution. Vortex to mix thoroughly.
5. Incubate at 60°C for 45 minutes with occasional mixing.
6. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
7. Add 225 µL BL Buffer. Vortex to mix thoroughly.

E.Z.N.A.® Forensic DNA Kit Protocols

8. Incubate at 60°C for 10 minutes.
9. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
10. Add 300 µL 100% isopropanol. Vortex to mix thoroughly.
11. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
12. Insert a HiBind® DNA Mini Column into a 2 mL Collection Tube.

Optional Protocol for Column Equilibration:

1. Add 100 µL 3M NaOH to the HiBind® DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Centrifuge at maximum speed for 30 seconds.
 4. Discard the filtrate and reuse the collection tube.
13. Transfer the entire sample from **Step 11** to the column, including any precipitate that may have formed.
 14. Centrifuge at maximum speed for 1 minute.
 15. Discard the filtrate and the collection tube.
 16. Transfer the HiBind® DNA Mini Column to a new 2 mL Collection Tube.
 17. Add 500 µL HBC Buffer.
Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.
 18. Centrifuge at maximum speed for 1 minute.

E.Z.N.A.[®] Forensic DNA Kit Protocols

19. Discard the filtrate and the collection tube.
20. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.
21. Add 700 μ L DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

22. Centrifuge at maximum speed for 1 minute.
23. Discard the filtrate and reuse the collection tube.
24. Repeat Steps 21-23 for a second DNA Wash step.

25. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

26. Place the column into a 1.5 mL or 2.0 mL nuclease-free microcentrifuge tube (not provided).
27. Add 100 μ L Elution Buffer heated to 70°C.
28. Let sit at room temperature for 3 minutes.
29. Centrifuge at maximum speed for 1 minute.
30. Repeat Steps 27-29 for a second elution step.

Note: Incubation at 70°C will give a modest increase in DNA yield per elution. Using the first eluate for the second elution will increase DNA concentration.

E.Z.N.A.[®] Forensic DNA Kit Protocols

Saliva

Materials and Reagents to be Supplied by User:

-
- Microcentrifuge capable of 14,000g
- Vortexer
- Water baths or heat blocks capable of 60°C and 70°C
- 15 mL centrifuge tubes
- 1.5 mL or 2.0 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- PBS
- 100% ethanol
- 100% isopropanol
- Optional: RNase A
- Optional: 3M NaOH

Before Starting:

- Heat the Elution Buffer to 70°C
 - Heat the water bath or heat block to 60°C
 - Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4
1. Collect 1.5 mL saliva in a 15 mL centrifuge tube (not provided) containing 6 mL PBS. Vortex to mix thoroughly.
 2. Centrifuge at 2,000g for 5 minutes.
 3. Aspirate and discard the supernatant.
 4. Add 180 µL PBS and resuspend the pellet.
 5. Transfer the sample to a new 1.5 mL or 2.0 mL nuclease-free microcentrifuge tube (not provided).

Note: If RNA-free DNA is desired, add 20 µL RNase A to the sample. Let sit at room temperature for 5 minutes.

E.Z.N.A.® Forensic DNA Kit Protocols

6. Add 25 μ L Proteinase K Solution.
7. Add 200 μ L BL Buffer. Vortex for 30 seconds to mix thoroughly.
8. Incubate at 60°C for 15 minutes with occasional mixing.
9. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
10. Add 200 μ L 100% ethanol. Vortex to mix thoroughly.
11. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
12. Insert a HiBind® DNA Mini Column into a 2 mL Collection Tube.

Optional Protocol for Column Equilibration:

1. Add 100 μ L 3M NaOH to the HiBind® DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Centrifuge at maximum speed for 30 seconds.
 4. Discard the filtrate and reuse the collection tube.
13. Transfer the entire sample from **Step 11** to the column, including any precipitate that may have formed.
 14. Centrifuge at maximum speed for 1 minute.
 15. Discard the filtrate and the collection tube.
 16. Transfer the HiBind® DNA Mini Column to a new 2 mL Collection Tube.
 17. Add 500 μ L HBC Buffer.

Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.

E.Z.N.A.[®] Forensic DNA Kit Protocols

18. Centrifuge at maximum speed for 1 minute.

19. Discard the filtrate and the collection tube.

20. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.

21. Add 700 μ L DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

22. Centrifuge at maximum speed for 1 minute.

23. Discard the filtrate and reuse the collection tube.

24. Repeat Steps 21-23 for a second DNA Wash step.

25. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

26. Place the column into a 1.5 mL or 2.0 mL nuclease-free microcentrifuge tube.

27. Add 100 μ L Elution Buffer heated to 70°C.

28. Let sit at room temperature for 3 minutes.

29. Centrifuge at maximum speed for 1 minute.

30. Repeat Steps 27-29 for a second elution step.

Note: Incubation at 70°C will give a modest increase in DNA yield per elution. Using the first eluate for the second elution will increase DNA concentration.

E.Z.N.A.[®] Forensic DNA Kit Protocols

Hair, Nails, and Feathers

IMPORTANT: Additional Reagents May Be Required

This protocol requires more reagent volumes exceeding those provided in the standard kit protocol, depending on the number of samples processed. The following reagents will need to be purchased separately:

- [BL Buffer](#)
- [TL Buffer](#)

Materials and Reagents to be Supplied by User:

-
- Microcentrifuge capable of 14,000g
- Vortexer
- Water baths or heat blocks capable of 60°C and 70°C
- 1.5 mL or 2.0 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- 1M DTT (dithiothreitol)
- PBS
- 100% ethanol
- 100% isopropanol
- Optional: 3M NaOH

Before Starting:

- Heat the water bath or heat block to 60°C
- Heat the Elution Buffer to 70°C
- Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4

1. Cut the sample into small pieces (0.5-1 cm) and transfer to a 1.5 mL nuclease-free microcentrifuge tube (not provided).

Tip: For hair, cut from base of hair; for feathers, select the primary feathers. (Large birds, secondary tail, or breast feather can be use).

2. Add 250 µL TL Buffer.
3. Add 25 µL Proteinase K Solution.

E.Z.N.A.[®] Forensic DNA Kit Protocols

4. Add 20 μ L 1M DTT. Vortex to mix thoroughly.
5. Incubate at 60°C for 30 minutes with occasional mixing.
6. Add 250 μ L BL Buffer. Vortex to mix thoroughly.
7. Add 250 μ L 100% ethanol. Vortex to mix thoroughly.
8. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
9. Insert a HiBind[®] DNA Mini Column into a 2 mL Collection Tube.

Optional Protocol for Column Equilibration:

1. Add 100 μ L 3M NaOH to the HiBind[®] DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Centrifuge at maximum speed for 30 seconds.
 4. Discard the filtrate and reuse the collection tube.
10. Transfer the entire sample from **Step 8** to the column, including any precipitate that may have formed.
 11. Centrifuge at maximum speed for 1 minute.
 12. Discard the filtrate and the collection tube.
 13. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.
 14. Add 500 μ L HBC Buffer.

Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.

E.Z.N.A.[®] Forensic DNA Kit Protocols

15. Centrifuge at maximum speed for 1 minute.
16. Discard the filtrate and the collection tube.
17. Transfer the HiBind[®] DNA Mini Column to a new 2 mL Collection Tube.
18. Add 700 μ L DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

19. Centrifuge at maximum speed for 1 minute.
20. Discard the filtrate and reuse the collection tube.
21. Repeat Steps 18-20 for a second DNA Wash step.
22. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

23. Place the column into a 1.5 mL or 2.0 mL nuclease-free microcentrifuge tube.
24. Add 100 μ L Elution Buffer heated to 70°C.
25. Let sit at room temperature for 3 minutes.
26. Centrifuge at maximum speed for 1 minute.
27. Repeat Steps 24-26 for a second elution step.

Vacuum/Spin Protocol

Materials and Reagents to be Supplied by User:

- Vacuum manifold
- Vacuum pump or vacuum source
- 1.5 mL or 2.0 mL nuclease-free microcentrifuge tubes
- Nuclease-free pipette tips
- Microcentrifuge capable of 14,000*g*
- Vortexer
- Water baths or heat blocks capable of 55°C, 60°C and 70°C
- 100% ethanol
- 100% isopropanol
- Optional: 3M NaOH

Before Starting:

- Prepare the DNA Wash Buffer and HBC Buffer according to the instructions in the Preparing Reagents section on Page 4
- Heat the water baths or heat blocks to 55°C and 60°C
- Heat the Elution Buffer to 70°C

Note: Please read through the previous sections of this manual before using this protocol.

1. Cut or punch out the blood spot (or other sample) from the filter paper. (Up to 200 μ L of blood can be used for each spot.) Tear or cut filter into small pieces and place into a microcentrifuge tube (not provided).

Note: Use 3-4 punched circles (3 mm diameter) for each DNA isolation.

2. Add 200 μ L TL Buffer. Vortex to mix thoroughly.
3. Incubate at 55°C for 15 minutes. Vortex every 2 minutes to mix.
4. Add 25 μ L Proteinase K Solution. Vortex to mix thoroughly.

E.Z.N.A.® Forensic DNA Kit Protocols

5. Incubate at 60°C for 45 minutes with occasional mixing.
6. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
7. Add 225 µL BL Buffer. Vortex to mix thoroughly.
8. Incubate at 60°C for 10 minutes.
9. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
10. Add 300 µL 100% isopropanol. Vortex to mix thoroughly.
11. Centrifuge at maximum speed to collect any sample adhering to the cap/walls of the tube.
12. Prepare the vacuum manifold according to manufacturer's instructions.
13. Connect the HiBind® DNA Mini Column to the manifold.

Optional Protocol for Column Equilibration:

1. Add 100 µL 3M NaOH to the HiBind® DNA Mini Column.
 2. Let sit at room temperature 4 minutes.
 3. Turn on the vacuum source to draw the NaOH through the column.
 4. Turn off the vacuum.
-
14. Transfer the sample from **Step 11** to the HiBind® DNA Mini Column.
 15. Turn on the vacuum source to draw the sample through the column.
 16. Turn off the vacuum.

E.Z.N.A.[®] Forensic DNA Kit Protocols

17. Add 500 μ L HBC Buffer.

Note: HBC Buffer must be diluted with 100% isopropanol before use. Please see Page 4 for instructions.

18. Turn on the vacuum source to draw the HB Buffer through the column.

19. Turn off the vacuum.

20. Add 700 μ L DNA Wash Buffer.

Note: DNA Wash Buffer must be diluted with 100% ethanol before use. Please see Page 4 for instructions.

21. Turn on the vacuum source to draw the DNA Wash Buffer through the column.

22. Turn off the vacuum.

23. Repeat Steps 20-22 for a second DNA Wash step.

24. Transfer the HiBind[®] DNA Mini Column to a 2 mL Collection Tube.

25. Centrifuge at maximum speed for 2 minutes to dry the column.

Note: It is critical to remove all residual ethanol that might interfere with downstream applications.

26. Transfer the HiBind[®] DNA Mini Column to a 1.5 mL nuclease-free microcentrifuge tube.

E.Z.N.A.[®] Forensic DNA Kit Protocols

27. Add 30-50 μ L Elution Buffer.

28. Let sit at room temperature for 1-2 minutes.

29. Centrifuge at 8,000 $\times g$ for 1 minute.

30. Store DNA at -20°C.

Troubleshooting Guide

Please use this guide to troubleshoot any problems that may arise. For further assistance, please contact the technical support staff, toll free, at (800-832-8896).

Problem	Cause	Solution
Clogged Column	Incomplete lysis	Extend incubation time with TL Buffer and Proteinase K Solution. Add the correct volume of BL Buffer and incubate for specified time at 70°C. Extend incubation time by 10 minutes if needed.
	Sample too large	If using more than 30 mg tissue, increase volumes of Proteinase K Solution, TL Buffer, BL Buffer, and ethanol. Pass aliquots of lysate through the column successively.
	Sample too viscous	Divide sample into multiple tubes, adjust volume to 250 µL with 10 mM Tris-HCl.
Low DNA Yield	Clogged column	See above
	Poor sample release from collection paper	Incubate the specimen collection paper longer in TL Buffer. Shake the tubes frequently.
	Poor elution	Repeat elution or increase elution volume (see note on Page 4). Incubation of column at 70°C for 5 minutes with Elution Buffer may increase yields.
	Improper washing	DNA Wash Buffer must be diluted with 100% ethanol as specified on Page 4 before use.
Low A_{260}/A_{280} ratio	Extended centrifugation during elution step	Resin from the column may be present in eluate. Avoid centrifugation at speeds higher than specified. The material can be removed from the eluate by centrifugation. It will not interfere with PCR or restriction digests.
	Poor cell lysis due to incomplete mixing with BL Buffer	Repeat the procedure. Immediately vortex the sample thoroughly with BL Buffer.
	Incomplete cell lysis or protein degradation due to insufficient incubation	Increase incubation time with TL Buffer and Proteinase K Solution. Ensure that no visible pieces of tissue remain.
	Samples are rich in protein	After applying to column, wash with 300 µL of a 1:1 mixture of BL Buffer:ethanol and then wash with DNA Wash Buffer.
No DNA Eluted	Poor cell lysis due to improper mixing with BL Buffer	Mix thoroughly with BL Buffer prior to loading the HiBind® DNA Mini Column.
	Poor cell and/or protein lysis in TL Buffer	Tissue sample must be cut or minced into small pieces. Increase incubation time at 65°C with TL Buffer to ensure that tissue is completely lysed.
	Ethanol not added to BL Buffer	Before applying sample to column, an aliquot of BL Buffer/ethanol must be added. See protocol above.
	No ethanol added to the DNA Wash Buffer	Dilute DNA Wash Buffer with the indicated volume of 100% ethanol before use.
	Isopropanol not added to HBC Buffer	Dilute HBC Buffer with 100% isopropanol before use.
Colored residue in column	Incomplete lysis due to improper mixing with BL Buffer	BL Buffer is viscous and the sample must be vortexed thoroughly.
	Ethanol was not added to DNA Wash Buffer	Dilute DNA Wash Buffer with 100% ethanol before use.

Notes:

For more purification solutions, visit www.omegabiotek.com

AVAILABLE FORMATS



Spin Columns



96-Well Silica Plates



Mag Beads

SAMPLE TYPES



Blood / Plasma



Plasmid



Cultured Cells



Plant & Soil



NGS Clean Up



Tissue








FFPE






Fecal Matter



 Omega Bio-tek, Inc.
400 Pinnacle Way, Suite 450
Norcross, GA 30071
 www.omegabiotek.com

 770-931-8400
 770-931-0230
 info@omegabiotek.com

 [omegabio-tek](https://www.linkedin.com/company/omegabio-tek)
 [omegabiotek](https://twitter.com/omegabiotek)
 [omegabiotek](https://www.facebook.com/omegabiotek)